



Install fitting and dry fit couplers,





Slide one coupler back at a time.
Prime and glue both fitting
body and pipe.



Twist coupler back onto glued pipe until arrows on fitting are fully exposed, Hold until set,